



### SETUP INSTRUCTIONS

Step 1: Each pole has a number at each end which matches that end with the end of another pole (A). Connect all the poles together with the matching number by pressing the spring post in and aligning it with the hole in the matching pole (B). Assembly is easiest if the frame is lying flat on the floor. If the center poles don't have any spring posts, just slide them together. The finished frame should look like figure (C).

Step 2: Arrange the fabric graphic so the zipper is facing downward and put the fabric over one corner, then stretch it to the other side and pull it down over the frame. The fabric will be taut, which is a good time to align the fabric so the graphic is even on the left and right (D).

Step 3: Pull the rest of the fabric down until the zipper starts to come around the frame. It's easiest to close the zipper by pulling the fabric over the pole and holding it with one hand. Then pull the zipper up to the hand holding the fabric, and repeat the process until the zipper is closed. Now that the fabric graphic is on the frame, adjust the fabric as needed to straighten the graphic. The Sophora display is now complete (E).

### PARTS

- (a) Frame poles (17)
- (b) Printed Fabric Graphic (1)