




(C)



(D)



(E)



SETUP INSTRUCTIONS

Step 1: Each pole has a number at each end which matches that end with the end of another pole (A). Connect all the poles together with the matching number by sliding the tubes together until the button clicks (B). Assembly is easiest if the frame is lying flat on the floor. If some poles are harder to connect, try to wiggle them while pushing the joint together. The finished frame should look like figure (C).

Step 2: Arrange the fabric graphic so the zipper is facing downward, and put the fabric over one corner of the frame, then stretch it to the other side and pull it down over the frame. This is a good time to align the fabric so the graphic is even on the left and right (D).

Step 3: Pull the rest of the fabric down until the fabric starts to come around the frame. It's easiest to close the zipper by pulling the fabric over the pole and holding it with one hand. Then pull the zipper up to the hand holding the fabric, and repeat the process until the zipper is closed. Now that the fabric graphic is on the frame, adjust the fabric as needed to straighten the graphic. The Sophora display is now complete (E).

PARTS

- (a) Frame poles (14)
- (b) Frame elbows (4)
- (c) Printed Fabric Graphic (1)