



Setup Instructions

Step 1: Slide Aluminum Foot **A** into Bottom Profile **B** until it reaches the midpoint.

Step 2: Slide Plastic Pole Connector **C** into Top Profile **D** until it reaches the midpoint. Insert Four Part Pole **E** into Aluminum Foot **A** at the bottom and Plastic Pole Connector **C** at the top

Step 3: Insert Top Endcaps **F** into Top Profile **D**, and the Bottom Endcaps **G** into Bottom Profile **B**.

Parts

- AAluminum Foot
- B.....Bottom Profile
- C.....Plastic Pole Connector
- DTop Profile
- E.....Four Part Pole
- F.....Top Endcap 2pcs
- GBottom Endcap 2pcs

ATTENTION: Please make sure the inner pole extends a minimum of 1 to 1.5 inches out from outer pole. If the inner pole is pushed in, the pole may crack and break. Be sure to pull the inner pole out to the recommended length to avoid damage.

Be sure to protect the end of the poles from being dropped on their end during shipping. Dropping the pole on end may cause the inner pole to be pushed inside the outer pole. Wrapping with bubble wrap is recommended, and always inspect the poles after shipping.

Luna Banner Stand