

If you are attaching a Sidewall to backwall, or other Varia.Sophora display, the base feet will look different. There will be 2 mounting post. The side wall and backwall will share the same foot. You will know which foot to use because the button will face inside the display. Attach the backwall, or largest Varia.Sophora display first. This will add stability and make it easier to attach the smaller Sidewall.

