


ASSEMBLED VIEW



SETUP INSTRUCTIONS

Step 1: Remove the Event Tent from it's case, and place it in the center of the set-up area.

Step 2: With partners on opposite sides, pull the legs away to spread them apart.

Step 3: Grab the bottom of the center truss bar to lift and spread the frame until almost fully extended.

Step 4: Engage the locks by pushing the slider into position on all 4 corners.

Step 5: Extend the legs of the tent by standing on the base and lifting until the lock engages. Lift 2 legs on a side, then repeat for the other side.

Roof Instructions:

Step 1: Unfold the fabric roof and drape over the extended tent hardware.

Step 2: Line-up the corners and attach the Velcro strips.

Backwall Instructions:

Step 1: Velcro the top of the backwall to the inside of the roof.

Step 1: Attach Velcro strips around the legs.

Skirt Instructions:

Step 1: Slid the Skirt Rail through the pocket on top of the skirt fabric.

Step 2: Clamp the rail to the legs of the tent. Adjust the quick release bolt for a tight grip.