



STEP 1. Layout all the parts on the floor in this form. Assembly will be done flat on the floor, not standing up.





START HERE








STEP 2. Start in this corner. Push the button with your thumb while sliding the tubes together. Twist as needed to click the button into the hole. Some buttons may already be inserted into one end of each tube. Face all buttons towards the inside of the frame. Stickers are next to the correct button hole.




CAUTION
Pinch Point
Keep finger clear of gaps between tubes.




Parts Count:

-  **C90 (4x)**
-  **C15 (7x)**
-  **10" S10 (2x)**
-  **18" S18 (2x)**
-  **32" S32 (6x)**
-  **Diagram A AHUB (2x)**
-  **Diagram B AHUB/A60 (2x)**

STEP 3. With the completed frame laying down on the floor, begin installing the graphics sliding the fabric over the bottom base corners of the frame, like a pillow case. Switching from the right and left side, slide the fabric up a little bit at a time. When it reaches the top, zip the top closed, then zip the side zipper.




WASH HAND
Before Handling Graphics



STEP 4. When the zipper reaches the top, the fabric becomes tighter. Pull the fabric firmly with one hand around the top tube while zipping the graphic closed with the other hand.

STEP 5. Once zipped closed, the display is ready to stand up. There are openings sewn at the top for installing lights. The electrical cords can be run inside of the graphics and out the bottom where the zipper shuts. Fit the light peg into the hole on top of the tube.



ASSEMBLED VIEW:

